FOXGEAR

The Foxgear ANUBI series consists of two different devices: the Ambient BOX (Blue) and the Modulation BOX (Pink). Based on the trusty FV-1 Digital processor used in many boutique pedals, including our award winning Rainbow, the Anubi boasts a super bright LCD display, visible in any light conditions, and a super easy-to-use interface:

- Stereo Engine (input & output)
- Midi interface to manage Presets and EXP.

Power In

Mono IN (L) Mono Out (L)

Consumption at 9V

Output Impedance

Larghezza (Width)

Altezza (Height)


Peso (Weight)

Lunghezza (Lenght)

Input Impedance

- 16 Algorithms
- 128 Presets Available
- 16 Midi Programmable Channels
- LCD display
- Analog MIX
- Digital Programmable Mix
- 100% Analog Signal Path
- Class A buffered Bypass with Relay

The Anubi Box is the perfect addition to your pedalboard or your Amplifier's FX Loop as a master FX unit. Anubi is able to give you one of the widest choice of premium designed Algorithms both for Ambient (Reverb, Delays, Chorus) or Modulation (Chorus, Phaser, Tremolo, Leslie, Flanger) and even some together (Rev+Dly, Rev+Chorus, etc..). You can easily manage it by Midi pedalboard, or Midi Looper/Switcher To Change up to 128 Presets with 16 different Algorithms and also use Control Change to assign an expression pedal to modify each parameter like delay time, levels, speed, or pitch shifting to obtain a fully working Whammy effect.



TECH SPECS.

9 to 12VDC (negative TIP) (Can accept Mono input with Stereo Out) 70mA <=1M Ohm <=10K Ohm 90mm. (3,5") 127mm. (5") 30mm. (1,2") 0,2Kq. (0,4lbs)

ANUB Preset:001 Alg:CELESTIA

Terms of Warranty

FOXGEAR product warranty covers 5 years from date of purchase The warranty does not cover damage caused by accident, misuse and / or neglect, failure to comply with the instruction manual, repair and attempted repair by personnel not authorized by FOXGEAR LLC, any damage caused during transport and delivery, (claims must be presented to the carrier); damage to any product that has been altered or on which it has been removed, defaced or altered serial number; damage caused by faulty connections or connections to equipment failures and/or defective power cables.

Responsibility of FOXGEAR LLC for any defective product is limited to repair or replacement of the product at our discretion. The FOXGEAR LLC not be liable for damages resulting from loss of use of the product, lost time operation interrupted by non-use of the product, loss of business or any other damages or incidental, consequential or otherwise; damage in transit or damage caused by inadequate packaging or of poor quality.

Assistance: Please contact us for information on how, where and when to ship the product after the return has been Authorized by FOXGEAR LLC. The repaired goods should be packed carefully and we recommend not include any accessories such as cables, effects, manuals, etc.

Please attach a copy of the original receipt of purchase (invoice or receipt) together with a problem description and your personal details

THE WARRANTY IS NOT VALID WITHOUT A COPY OF YOUR RECEIPT OF SALE CERTIFYING THE DATE OF PURCHASE.

Foxgear pedals are designed in Italy and proudly handmade in our own factory in PRC.

FOXGEAR LLC 2011 Westley Ct, Safety Harbor, 34695 Florida - USA support@foxgeardistribution.com



FUNCTIONS:

THE AMBIENT BOX

Scrolling the EDIT knob, you can set the different Algorithms and by pushing the Edit knob, you can access to the menu to modify all the parameters and values. Then you can push and Hold EDIT and push the Jog Shuttle to Save all the parameters to the selected preset. Very Easy! The Signal path is 100% analog and with Audio capacitors (no SMD) in the Audio Path, so the quality and dynamics are intact and superb.

The Main MIX set the general Analog MIX of the pedal over the Clean signal that always passes thru the pedal without being digitally converted to preserve the quality.

An additional digital mix is present in all the presets, which lets you modify and recall/save it to the desired level, from 100% WET, to the complete Bypass of the whole pedal.

- PRESETS SAVING PROCEDURE:

Push and hold EDIT and then push the Jog Shuttle.

- MIDI CHANNEL PROCEDURE:

By Keeping the EDIT control pushed for more than 3sec. you access to the MIDI menu, where you can select the Midi Channel from 1 to 16. Just select and wait until autosaving and exit.

ANUBI AMBIENT BOX - ALGORITHMS/CONTROLS LIST:			
ALGORITHM NAME:	POT #1	POT #2	POT #3
1) CHURCH = Large Room Reverb	1) HIF= Hi Frequency Filter	1) PDL = Pre-Delay	1) DCY= Decay
2) PLATE = Vintage long Reverb	2) HIF= Hi Frequency Filter	2) PDL = Pre-Delay	2) DCY= Decay
3) HALL = Large Room Reverb	3) HIF= Hi Frequency Filter	3) MOD = Modulation	3) DCY= Decay
4) ROTARYVERB = Verb + Rotary	4) HIF= Hi Frequency Filter	4) MOD = Rotary Intensity	4) DCY= Decay
5) SPRING 1 = Vintage Spring Reverb	5) HIF= Hi Frequency Filter	5) FAT = Springs Bias	5) DCY= Decay
6) SPRING 2 = Vintage Spring Reverb	6) HIF= Hi Frequency Filter	6) MOD = Ref Phase Mod.	6) DCY= Decay
7) CELESTIAL = Shimmering Reverb	7) HIF= Hi Frequency Filter	7) SHM = Shimmer Intensity	7) DCY= Decay
B) ETHEREAL = Shimmering Reverb	8) HIF= Hi Frequency Filter	8) SHM = Shimmer Intensity	8) DCY= Decay
9) SHIMMER = Shimmering Reverb	9) BAL= Shimmering Balance	9) SHM = Shimmer Intensity	9) DCY= Decay
10) RELAY = Reverb + Delay	10) DTM = Delay Time (730ms max)	10) RVB = Room Size	10) FBK= Feedback
11) HOT RHODES = Smooth Mod Reverb	11) HIF= Hi Frequency Filter	11) RVB = Room Size	11) DCY= Decay
12) AQUA = Verb+Rotor+Modulation	12) HIF= Hi Frequency Filter	12) SPD = Mod Speed	12) DCY= Decay
13) VIBERB = Vibe + Reverb	13) RVL = Reverb Level	13) SPD = Vibe Speed	13) VBL = Vibe Level
14) STEREO ECHO= Stereo Heads Echo	14) RCM = Right Channel FX Level	14) -	14) FBK= Feedback
15) DUOMO = Bigger Church Reverb	15) HIF = Hi Frequency Filter	15) PDL = Pre-Delay	15) DCY= Decay
16) ECHO SWELL = 4Heads drum echo	16) RCM = Right Channel FX Level	16) -	16) FBK= Feedback